

Touch Point

Comfort management touch panels

TP-B, TP-H-B, TP-C-B, TP-HC-B, TP-DISP-B, TP-H-DISP-B,
 TP-C-DISP-B, TP-HC-DISP-B, TP-W, TP-H-W, TP-C-W, TP-HC-W,
 TP-DISP-W, TP-H-DISP-W, TP-C-DISP-W, TP-HC-DISP-W



SPECIFICATION	
Power supply	DC: 20-34 V; AC: 24 V ± 20%
Temperature sensor	10k NTC type, Accuracy: ±0,5°C
Humidity sensor	(Optional) Range: 0-100% RH, Accuracy: ±2% RH in range 10-90% RH
CO2 sensor	(Optional) Range: 400-10000 ppm, Accuracy: ±30 ppm
Display	(Optional) TFT 0.96"
Interface	RS485, USB type C
Ingress protection	IP20 - for indoor installation
Temperature	Operating: 0°C to +40°C; Storage: -40°C to +70°C
Relative humidity	5 to 95% RH (without condensation)
Connectors	2x RJ45 terminal Screw terminal separable max 1.5 mm ² (26 ... 16 AWG)
Dimensions	86 x 86 x 14,5 mm (3.39 x 3.39 x 0.57 in)
Mounting	Standard 60 mm wall back box
Housing material	Plastic, self-extinguishing ABS

REAR VIEW		MOUNTING FRAME						
<p>Address configuration</p> <table border="1"> <tr> <td>1</td> <td>Restore default settings</td> </tr> <tr> <td>2</td> <td>Protocol: 0 = Modbus 1 = BACnet</td> </tr> <tr> <td>3</td> <td>Termination resistor: 0 = disconnected (default) 1 = connected</td> </tr> </table> <p>2x RJ45</p> <p>Power supply</p> <p>RS485 for Modbus or BACnet communication</p>		1	Restore default settings	2	Protocol: 0 = Modbus 1 = BACnet	3	Termination resistor: 0 = disconnected (default) 1 = connected	<p>TOP</p> <p>66</p> <p>60</p> <p>66</p>
1	Restore default settings							
2	Protocol: 0 = Modbus 1 = BACnet							
3	Termination resistor: 0 = disconnected (default) 1 = connected							
POWER SUPPLY	RJ45 PIN DESCRIPTION	MOUNTING VIEW						
<p>Power supply from 24 V AC/DC PELV/SELV source</p> <p>Internal connections</p> <p>RJ45 RJ45 Screw terminal</p>	<p>1 - NC 8 - G0</p> <p>2 - NC 7 - G</p> <p>3 - RS485+ 6 - RS485-</p> <p>4 - G 5 - G0</p>	<p>1</p> <p>2</p> <p>USB Slot</p> <p>3</p> <p>4</p> <p>PH1</p>						
COMMUNICATION								
<p>COM RS485- RS485+</p> <p>COM RS485- RS485+</p> <p>RS485+ RS485- COM</p> <p>Communication cable twisted, shielded</p> <p>RS485 Modbus or BACnet</p> <p>Internal connections</p> <p>RJ45 RJ45 Screw terminal</p>								



Please read the instruction before use or operating the device. In case of any questions after reading this document, please contact the iSMA CONTROLLI Support Team (support@ismacontrolli.com).



- Before wiring or removing/mounting the product, make sure to turn the power off. Failure to do so might cause an electric shock.
- Improper wiring of the product can damage it and lead to other hazards. Make sure that the product has been correctly wired before turning the power on.
- Do not touch electrically charged parts such as power terminals. Doing so might cause an electric shock.

• Do not disassemble the product. Doing so might cause an electric shock or faulty operation.



• Use the product only within the operating ranges recommended in the specification (temperature, humidity, voltage, shock, mounting direction, atmosphere, etc.). Failure to do so might cause a fire or faulty operation.

• Firmly tighten the wires to the terminal. Failure to do so might cause a fire.

• Avoid installing the product in close proximity to high-power electrical devices and cables, inductive loads, and switching devices. Proximity of such objects may cause an uncontrolled interference, resulting in an instable operation of the product.

• Proper arrangement of the power and signal cabling affects the operation of the entire control system. Avoid laying the power and signal wiring in parallel cable trays. It can cause interferences in monitored and control signals.

• It is recommended to power controllers/modules with AC/DC power suppliers. They provide better and more stable insulation for devices compared to AC/AC transformer systems, which transmit disturbances and transient phenomena like surges and bursts to devices. They also isolate products from inductive phenomena from other transformers and loads.

• Power supply systems for the product should be protected by external devices limiting overvoltage and effects of lightning discharges.

• Avoid powering the product and its controlled/monitored devices, especially high power and inductive loads, from a single power source. Powering devices from a single power source causes a risk of introducing disturbances from the loads to the control devices.

• If an AC/AC transformer is used to supply control devices, it is strongly recommended to use a maximum 100 VA Class 2 transformer to avoid unwanted inductive effects, which are dangerous for devices.

• Long monitoring and control lines may cause loops in connection with the shared power supply, causing disturbances in the operation of devices, including external communication. It is recommended to use galvanic separators.

• To protect signal and communication lines against external electromagnetic interferences, use properly grounded shielded cables and ferrite beads.

• Switching the digital output relays of large (exceeding specification) inductive loads can cause interference pulses to the electronics installed inside the product. Therefore, it is recommended to use external relays/contactors, etc. to switch such loads. The use of controllers with triac outputs also limits similar overvoltage phenomena.

• Many cases of disturbances and overvoltage in control systems are generated by switched, inductive loads supplied by alternating mains voltage (AC 120/230 V). If they do not have appropriate built-in noise reduction circuits, it is recommended to use external circuits such as snubbers, varistors, or protection diodes to limit these effects.



Electrical installation of this product must be done in accordance with national wiring codes and conform to local regulations.