

## **SSI-DR-SMSIP Driver**

Software installation and configuration manual.

Ver: 2.3.0.1

Date: 23.8.2022

Author: S. Strapparava

## History

Filename: ssiSMSIP_v2.3.0.1.odt			
Rev.	Date	Author	Description
1.0	11.09.2020	S. Strapparava	First draft
1.0.3	02.10.020	S. Strapparava	1.0.3
2.2.1.0	21.03.2021	S. Strapparava	2.2.1.0
2.3.0.0	06.04.2021	S. Strapparava	2.3.0.0
2.3.0.1	29/04/21	S. Strapparava	Changes on configuration interface Chapter 4 – Driver configuration Capter 6 – How to create a simulator
	23.8.2022	M.Meriano	Update dreiver for N4.7+N4.8+N4.9+N4.10+

# Index

History .....	2
Index .....	3
Confidentiality Notice .....	4
1 . Introduction .....	5
Requirements .....	5
Module.....	5
Compatibility.....	5
2 . License.....	6
3 . Installing the software .....	7
Installing the driver into the JACE/HAWK unit.....	8
4 . Driver configuration.....	9
Installing the SsiSmsWSService .....	9
Configuring the Network Parameters .....	10
Install and configuring the SmsRecipient.....	12
Add Users in SmsRecipient .....	12
Configure the Text of the SMS message .....	15
Configure SmsSender .....	16
5 . Acknowledgement.....	17
6 . How to create a simulator .....	17

## Confidentiality Notice

The information contained in this document is confidential information of Smart Services International Sagl (“SSI”).

Such information and the software described herein, is furnished under license agreement and may be used only in accordance with that agreement.

The information contained in this document is provided solely for use by SSI employees, licenses and system owners. Contents of this document are not to be released to or reproduced for anyone else.

While every effort has been made to assure the accuracy of this document, SSI is not responsible for damages of any kind, including without limitation consequential damages, arising from the application of the information contained herein. Information and specifications published here current as of the date to this publication and are subject to change without notice.

This document may be copied by parties who are authorised to distribute SSI products in connection with distribution of those products, subject to the contracts that authorize such distribution. It may not otherwise, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form without prior written consent from SSI.

## 1 . Introduction

### Requirements

- Niagara 4.x ( $\geq 4.4$ )
- A license to use the SSI-DR-SMSIP driver. Other device limit or proxy-point limits may apply to your license. For license details and options, see the SSI-DR-SMSIP price list.

### Module

The SSI-DR-SMSIP Driver is contained in two files:

- `ssiSMSIP-rt.jar`
- `ssiSMSIP-wb.jar`

## Compatibility

### Platforms

The SSI-DR-SMSIP driver runs on Niagara 4.x (>= 4.4) platforms.

### Tested versions

Niagara 4.9.x

## 2 . License

The `device.limit` number in your license, is referred to **registered and enabled** Mobile Phone numbers (User defined in SMSRecipient).

i.e.:

If your license has a `device.limit` of 5, you can register 5 (or more) different phone numbers in your station's database, but only 5 could be enabled simultaneously.

The same phone number can be registered many times (in different SMSRecipient), consuming only one license slot.

## 3 . Installing the software

Installing the SSI-DR-SMSIP driver is simple.

It requires a basic knowledge of the Tridium Niagara 4 and execute a few steps as described hereafter.

The driver, a Java “.jar” executable file, is usually shipped in a zip file.

Its name is generated according to the following structure:

`ssiSMSIP-rt_<version number>` ( i.e. `ssiSMSIP-rt_v1.0.3.1`)

`ssiSMSIP-wb_<version number>` ( i.e. `ssiSMSIP-wb_v1.0.3.1`)

The number of the version characterises the features included in the driver and may vary from time to time.

An additional text file is normally added to the zip file, in order to explain the main features of the release.

Its name may appear as follow:

**Note on SwVer <version number>** ( i.e. **Note on SwVer 1.0.3**)

Installing the driver on your PC

The following procedures describe how to set-up the driver.

Step 1	First of all unzip the files which contains the driver and technical notes.
--------	---

Step 2	Rename the files, changing their name into <b>ssiSMSIP-rt</b> and <b>ssiSMSIP-wb</b> Extension <b>.jar</b> should remain as well.
Step 3	Copy the two <b>jar</b> files into the <b>modules</b> directory of your Niagara <b>Work Bench</b> .
Step 4	Restart your <b>Work Bench</b> .
Step 5	After restarting, the file should appear in the list of available software, which can be shown clicking on the <b>Software Manager</b> section of the <b>Platform</b> of your <b>Work Bench</b> .


## Installing the driver into the JACE/HAWK unit

Step 1	Through the <b>Work Bench</b> get connected to a JACE/HAWK running unit.
Step 2	Transfer the <b>ssiSMSIP</b> module into the unit under the folder <b>modules</b> .
Step 3	<p>This can be done by activating the standard Tridium procedure for software upgrading or simply copying the <b>jar</b> files by the <b>File Transfer Client</b> procedure, available under the list of the <b>Platform</b> options in your <b>Work Bench</b>.</p> <p>Destination directory inside the Jace8000 is: <b>/opt/niagara/modules</b></p> <p>For further details on how to transfer files from <b>Work Bench</b> to JACE/HAWK units, refer to the official Tridium documentation.</p>
Step 4	After copying the driver into the JACE/HAWK unit, force a reboot.

## 4 . Driver configuration

### Installing the SsiSmsWSService

The first step of the driver configuration is the installation of the **SsiSmsWSService** under the station running in the JACE/HAWK unit.



The screenshot shows the Niagara configuration interface. On the left, the 'Nav' pane displays a tree view of components, with 'SmsWSService' selected. Below it, the 'Palette' pane shows the 'ssiSMSIP' component. On the right, the 'Property Sheet' for 'SmsWSService (Ssi Sms W S Service)' is displayed, showing various configuration parameters and their values.

Property	Value
Status	{ok}
Fault Cause	
Enabled	true
Ip Address	127.0.0.1
Driver Vendor	Smart Services International SAGL
Driver Version	2.3.0.0
Administrator	Ssi Administrator
Administrator Name	
Phone Number	
Modem	Ssi Modem
Sim Card Status	SIM Card inserted
Signal Quality	Good
Health	Ok [06 apr 2021 15:33 CEST]
Down	false
Last Ok Time	
Last Fail Time	
Last Fail Cause	
Monitor	Ssi W S Monitor
Sender	Ssi Sms Sender
Send Queue	0

A simple way to complete this task is to open the **PaLETTE** named **ssiSMSIP** (see figure below), select the **SsiSmsWSService** component and drag and drop it under the **Services** folder of the running station.

This component is a network-level component in the Niagara architecture. It provides the main configuration properties necessary to allow the driver to communicate with the SSI-HW-GATW Gateway.

## Configuring the Network Parameters

To proceed with this task, right click on the **SsiSmsWSService** (just dragged to station Services) and open its **Property Sheet**:

- Set the **"IP Address"** accordingly to SSI-HW-GATW IP address.

Here is a concise description of all the configuration parameters of the driver interface inside Niagara.

### Status

It shows the general Status of the driver ( i.e. Ok, fault etc.)

### Fault Cause

It Shows the reason of a faulty connection to the gateway ( i.e. Unable to connect to the SMS server at: ###.###.###.### IP Address)

#### **Enabled**

It is the switch to make the driver in ON status or OFF ( i.e. for maintenace)

#### **Ip Address**

It is the IP address of the SMS router gateway in your Network.

#### **Driver Vendor**

Smart Services International Sagl

#### **Driver Version**

It shows the current version of the installed driver.

#### **Administrator**

Administrator Name

Phone Number

If compiled, these fields are the references of delivery for the System Administrator who will receive a warning by SMS, when the daily limit of SMS messages sent is going to be reached. This works when the daily limit is set and activated (see Daily SMS limit here below).

#### **Modem**

**Sim Card Status**

It reports if the SIM card is present and correctly inserted.

**Signal Quality**

It returns the signal strength of the communication with the Mobile Network (i.e. Vodafone).

#### **Health**

**Down**

If it is True it warns on a communication problem.

**Last OK Time**

Date and time of the last Ok condition.

**Last Fail Time**

Date and time of the last Failure condition.

**Last Fail Cause**

Reports the last failure cause.

#### **Monitor**

Function not in use.

## Sender

Sender	Ssi Sms Sender
Daily Sms Limit	<input type="checkbox"/> false
Max Sendable Per Day	100
Number Sent Today	4
Last Date	29 apr 2021 00:00 CEST
Send Queue	0

### Daily SMS Limit

Inable/Disable the following options

### Max Sendable Per Day

Max number of messages allowed per day.

### Number Sent Today

Max number of messages sent during the current day.

### Last Date


Date of the last sent message.

### Send Queue

Number of messages sent during the current day.

## Installing and configuring the SmsRecipient


Select the **SmsRecipient** component in the palette and drag and drop it under the **Services** → **AlarmServices** folder of the running station.




Open the **SmsRecipient** wire sheet and link it to **Default Alarm**.

## Add Users in SmsRecipient


Double click on the **SmsRecipient** to access the **Sms User Manager**.




Click on **New** and choose how many users you want to add.




Add user details and save.





## Configure the Text of the SMS message

An important feature of the driver is the possibility to fully customise the SMS text.



### Time Range

It allows to limit the Alarm Service during the day. It is according to the standard Tridium rules.

Start Time: starting time of the service during the day;

End Time: ending time of the service during the day.

#### **Days of Week**

Days of the week when the Alarm Service is active.

#### **Transitions**

Alarm Service rules, according to Tridium standards.

#### **Route Aks**

According to Tridium standards.

#### **Enabled**

Enable/Disable the alarm SMS Service.

#### **Text**

In this filed it is possible to configure the structure of the text message sent as SMS.

The example shows how to get the Alarm State (i.e. New Alarm, Alarm Closed and so on). Syntax is the one of Niagara standard messages. Refer to Niagara documentation for further information.

### **IMPORTANT**

An important feature of the SSI-DR-SMSIP driver is that if this number (the pure UUID number only) is returned to the router as SMS, the alarm is automatically acknowledged inside the Tridium alarm console.

Here is an example.

SMS message incoming to a Mobile Phone:

**Alarm state: On going alarm!**

**Alarm: true**

**UUID: b14d9d0e-9618-43c5-b052-69460a91b373**

SMS message to be returned with the Mobile Phone:

**b14d9d0e-9618-43c5-b052-69460a91b373**

Then the alarm will be acknowledged in the alarm console of Niagara.


One important field is the UUID number, which represents the unique ID of any alarm generated inside Tridium Alarm Data Base.

## Configure SmsSender

Go back to `SsiSmsWSService` and select the `Sender` sub-component.

If you want to set a limit for SMS sendable in a single day, set `"Daily Sms Limit"` to `true`, and set the limit in `"Max Sendable per Day"` field.

If `"Daily Sms Limit"` is `false`, the value of `"Max Sendable per Day"` is ignored.



Sender		Ssi Sms Sender
Daily Sms Limit	<input checked="" type="checkbox"/>	true
Max Sendable Per Day	<input type="text"/>	10
Number Sent Today	<input type="text"/>	0
Last Date	<input type="text"/>	06 apr 2021 14:56 CEST
Send Queue	<input type="text"/>	0

Before the daily limit is reached, the administrator will be notified by SMS (see also Installing the `SsiSmsWSService` paragraph.)

After that, the SMS generated will be discarded, until the next day or until the daily limit is manually increased.

## 5 . Acknowledgement

To acknowledge an alarm using SMS, send an SMS containing only the alarm UUID (received in alert SMS) to the SIM card number of the SSI-HW-GATW.


See also “Configure the Text of the SMS message” paragraph for a full explanation.

## 6 . How to create a simulator


In order to test the driver, you can create a simulator in your station.

First complete the driver installation as explained in this document.

In your station create a dedicated folder named, for example, “**Alarm Generator**” or any other name which fits with your needs.




In its **Wire Sheet**, create a **Boolean Writable** point with a **Boolean Chang Of State Alarm Extension**, as shown in the following figure:




In the **Property Sheet** of the **Alarm Extension**, it is possible to specify the messages that will be generated and sent when the alarm occurs. All the other fields are according to Tridium standard rules.

Right click on the **Boolean Writable** component and select the **Set** option.

Then activate the alarm with the option **True** as shown:



An alarm will pop up in the alarm console:



Subsequent actions are:

1. The alarm will be immediately forwarded as SMS text message to the telephone numbers previously configured.
2. Setting the **Boolean Writable** to **False** will put the alarm in an **Offnormal** state and a new SMS message will be sent to the configured numbers stating that the Alarm is over..

3. Its content is according to the configuration made in the **SsiSmsRecipient**.
4. If from the Mobile Phone a return SMS will be sent containing the UUID only, the alarm will be automatically acknowledged in the Alarm Console.